



Water Heater Anodes

Magnesium Anodes

Anodes Rods are designed to protected the tank of a water heater by reducing internal corrosion. Periodic replacement of the anode rod prolongs the tank life. the anode rod includes a hex head for easy installation.

Anode Rods attract corrosive elements in water, so they attack the anode rod rather than the interior of your water heater's tank. Simply remove the plastic drain plug and insert the anode rod. When replacement is necessary, unscrew the old one and insert the new one.


Chemical Composition

Aluminium	2.5 - 3.5%
Manganese	0.2 - 1%
Zinc	0.7 - 1.3%
Silicon	0.05%
Copper 0.01%	0.01%
Nickel	0.001%
Iron	0.002%
Magnesium	balance



Water Heater Anodes Welded Screw - On Caps

Anode Diam.	Internal Thread	External Thread	A (in)	B (in)	C (in)	D (in)
0.500	1/4 - 18 NPT	3/4 - 14 NPT	1.060	0.81	0.19	0.63
0.675, 0.700, 0.75	3/8 - 18 NPT	3/4 - 18 NPT	1.060	0.87	0.19	0.63
0.840, 0, 900	1/2 - 14 NPT	3/4 - 14 NPT	1.060	0.87	0.19	0.63
1.050	3/4 - 14 NPT	1 - 11 ½ NPT	1.310	1.19	0.38	1.00
1.315	1 - 11 ½ NPT	1 1/4 - 11 ½ NPT	1.813	1.19	0.44	1.00



Corrosion Specialist

ELECTRO PROTECTION SERVICES INDIA (P) LTD
(AN ISO 9001:2008 CERTIFIED COMPANY)

Plot No:6, Cauvery Street, Guruswamy Nagar Extn., Sembakkam, Chennai 600 073.
Phone : 91 44 22780677 / 22781745, Fax : 91 44 22780688
Email: sales@epsipl.com, Website : www.epsipl.com